Overview of available "STANDARD" subframes and rail monting techniques with angles

SUBFRAMES	
A-Frame	To build out over an obstacle such as a doorhandle. Build out is for shutter housing and guide rails.
B-Frame	To build out from an obstacle where build out is needed for shutter housing, guide rails and sill angle.
Double I-Frame	To build out for the rails on each sides.
U - Frame	to build out for guide rails and bottom sill. A second cross bar for housing is not needed.
Reverse U - Frame (RU-Frame)	Where build out around a shutter is required but no bottom cross bar needed for sill angle or a second cross bar for the shutter housing.
O-Frame	Where build out around a shutter is required but no second cross bar needed for shutter housing.