



CRIPPLE STUDS AND RAFTERS MUST BE CUT TO ACCOMMODATE THE SOFFIT SHUTTER BOX. FACTORS TO CONSIDER ARE SHUTTER BOX SIZE, RAIL SIZE, SOFFIT LENGTH AND PLYWOOD SHUTTER BOX FRAMING. FINAL RESULT SHOULD BE THAT THE OUTSIDE OF THE SHUTTER RAIL IS FLUSH WITH THE SHEATHING FOR A HIDDEN RAIL. WINDOW MUST BE RECESSED AND PLACEMENT SHOULD BE CONSIDERED SO THAT MINIMUM SEPARATION IS MAINTAINED BETWEEN WINDOW AND SHUTTER CURTAIN. DETERMINING THE BEST INSTALLATION METHOD IS THE RESPONSIBILITY OF YOU AND YOUR ARCHITECT, ENGINEER OR CONSTRUCTION PROFESSIONAL.

RIGHT SIDE VIEW OF COMPLETED WALL SECTION



5331 W. Orange St.  
 Pearland, Tx. 77581  
 Tel: 281-485-0839  
 www.rollac.com