FOLLAC OUTDOORKEYSWITCHES

WIFING INSTRUCTIONS

AVAILABLE HEAVY DUTY OUTDOOR KEY SWITCHES

Momentary Key Switches:

Surface Mounted Key Switch:

Flush Mounted Key Switch:

Maintained Key Switches:


Surface Mounted Key Switch:

Flush Mounted Key Switch: -

8462-SWIT-07-XX

8464-SWIT-14-XX

8461-SWIT-07-XX 8463-SWIT-14-XX



IMPORTANT INFORMATION:

- the cover cannot be removed without the key.
- all switches are off in the vertical (center) position.
- keys can be removed from the momentary key switches only when the key is in the off position.
- keys can be removed from the maintained key switches in any of the three possible positions (Up, Down, or Off).
- each key switch can be used to operate only one (1) motor. care

WIRING DIAGRAM

